


INPUT ASSEMBLY 1  
TEST CONNECTOR TO C1 CONNECTOR

| Pin | SIU PIN | C1/C11 | SIU SIGNAL | Pin | C1/C11 | SIU PIN | SIU SIGNAL |
|-----|---------|--------|------------|-----|--------|---------|------------|
| 1   | A5      | C1-56  | IN6        | 14  | C1-49  | B11     | IN19       |
| 2   | B5      | C1-60  | IN7        | 15  | C1-67  | A12     | IN20       |
| 3   | A6      | C1-39  | IN8        | 16  | C1-69  | B12     | IN21       |
| 4   | B6      | C1-43  | IN9        | 17  | C1-51  | A13     | IN22       |
| 5   | A7      | C1-63  | IN10       | 18  | C1-52  | B13     | IN23       |
| 6   | B7      | C1-76  | IN11       | 19  | C1-73  | A14     | IN24       |
| 7   | A8      | C1-47  | IN12       | 20  | C1-74  | B14     | IN25       |
| 8   | B8      | C1-58  | IN13       | 21  | C1-82  | A15     | IN26       |
| 9   | A9      | C1-62  | IN14       | 22  | C1-81  | B15     | IN27       |
| 10  | B9      | C1-41  | IN15       | 23  | C1-53  | A16     | IN28       |
| 11  | A10     | C1-45  | IN16       | 24  | C1-80  | B16     | IN29       |
| 12  | B10     | C1-65  | IN17       | 25  |        |         | DC Ground  |
| 13  | A11     | C1-78  | IN18       |     |        |         |            |

NOTE : 26 thru 37 not used.

TEST CONNECTOR (Plug)




INPUT ASSEMBLY 2  
TEST CONNECTOR TO C1 CONNECTOR

| Pin | SIU PIN | C1/C11 | SIU SIGNAL | Pin | C1/C11 | SIU PIN | SIU SIGNAL |
|-----|---------|--------|------------|-----|--------|---------|------------|
| 1   | A5      | C1-55  | IN6        | 14  | C1-50  | B11     | IN19       |
| 2   | B5      | C1-59  | IN7        | 15  | C1-68  | A12     | IN20       |
| 3   | A6      | C1-40  | IN8        | 16  | C1-70  | B12     | IN21       |
| 4   | B6      | C1-44  | IN9        | 17  | C1-71  | A13     | IN22       |
| 5   | A7      | C1-64  | IN10       | 18  | C1-72  | B13     | IN23       |
| 6   | B7      | C1-77  | IN11       | 19  | C1-54  | A14     | IN24       |
| 7   | A8      | C1-48  | IN12       | 20  | C1-75  | B14     | IN25       |
| 8   | B8      | C1-57  | IN13       | 21  | C11-10 | A15     | IN26       |
| 9   | A9      | C1-61  | IN14       | 22  | C11-11 | B15     | IN27       |
| 10  | B9      | C1-42  | IN15       | 23  | C11-12 | A16     | IN28       |
| 11  | A10     | C1-46  | IN16       | 24  | C11-13 | B16     | IN29       |
| 12  | B10     | C1-66  | IN17       | 25  |        |         | DC Ground  |
| 13  | A11     | C1-79  | IN18       |     |        |         |            |

NOTE : 26 thru 37 not used.

TEST CONNECTOR (Plug)




INPUT ASSEMBLY 3  
TEST CONNECTOR TO C1 CONNECTOR

| Pin | SIU PIN | C1/C11 | SIU SIGNAL | Pin | C1/C11 | SIU PIN | SIU SIGNAL |
|-----|---------|--------|------------|-----|--------|---------|------------|
| 1   | A5      | C11-15 | IN6        | 14  |        | B11     | IN19       |
| 2   | B5      | C11-16 | IN7        | 15  |        | A12     | IN20       |
| 3   | A6      | C11-17 | IN8        | 16  |        | B12     | IN21       |
| 4   | B6      | C11-18 | IN9        | 17  |        | A13     | IN22       |
| 5   | A7      | C11-19 | IN10       | 18  |        | B13     | IN23       |
| 6   | B7      | C11-20 | IN11       | 19  |        | A14     | IN24       |
| 7   | A8      | C11-21 | IN12       | 20  |        | B14     | IN25       |
| 8   | B8      | C11-22 | IN13       | 21  |        | A15     | IN26       |
| 9   | A9      | C11-23 | IN14       | 22  |        | B15     | IN27       |
| 10  | B9      | C11-24 | IN15       | 23  |        | A16     | IN28       |
| 11  | A10     | C11-25 | IN16       | 24  |        | B16     | IN29       |
| 12  | B10     | C11-26 | IN17       | 25  |        |         | DC Ground  |
| 13  | A11     |        | IN18       |     |        |         |            |

NOTE : 26 thru 37 not used.

TEST CONNECTOR (Plug)



|  |       |
|--|-------|
| <b>TITLE:</b><br>C1/C11 PARALLEL<br>INTERFACE (INPUTS) |       |
| Rev Date 09-19-03                                      | A-1-1 |
| MAY 8, 2003  |       |