

1.1 Cabinet Details

05-08-03 Drawing Table of Contents Revised 12-01-03

| <i>REVISION</i> | <i>DRAWING NAME</i> | <i>PAGE</i> |
|-----------------|--|-------------|
| 09-30-03 | CABINET HOUSINGS # 1 AND # 2 | 6-5-1 |
| 09-08-03 | CABINET HOUSING # 3 – DETAIL 1 | 6-5-2 |
| 09-17-03 | CABINET HOUSING # 3 – DETAIL 2 | 6-5-3 |
| 10-08-03 | CABINET CAGES # 1 AND # 2 | 6-5-4 |
| 10-01-03 | CABINET CAGE TO HOUSING # 1 & # 2 SUPPORTS | 6-5-5 |
| 09-08-03 | CABINET CAGE TO HOUSING # 3 SUPPORTS | 6-5-6 |
| 11-24-03 | CABINET HOUSING # 2/ADAPTERS & SHIPPING PALLET | 6-5-7 |
| 10-08-03 | “J” PANELS – CAGE 1 | 6-5-8 |
| 10-08-03 | “J” PANELS – CAGE 2 | 6-5-9 |
| 10-03-03 | CONTROLLER SHELF/DRAWER SUPPORT ASSEMBLY | 6-5-10 |
| 10-03-03 | SERVICE PANEL ASSEMBLY CAGE 1 AND 2 | 6-5-11 |
| 09-17-03 | SERVICE PANEL ASSEMBLY SCHEMATIC | 6-5-12 |
| 09-05-03 | INPUT TERMINATION PANEL HOUSING #1 | 6-5-13 |
| 09-11-03 | AC CLEAN MODULE ASSEMBLY & HARNESS | 6-5-14 |
| 09-03-03 | RAW/CLEAN AC POWER ASSEMBLY & EXTENSION | 6-5-15 |
| 09-19-03 | RAW/CLEAN AC POWER ASSEMBLY WIRING DIAGRAM | 6-5-16 |
| 09-19-03 | DC POWER/COMMUNICATIONS ASSEMBLY & EXTENSION | 6-5-17 |
| 08-12-03 | DC POWER/COMMUNICATIONS ASSEMBLY WIRING DIAGRAM | 6-5-18 |
| 09-17-03 | PDA ITS – FRONT VIEW | 6-5-19 |
| 09-19-03 | PDA ITS - REAR VIEW | 6-5-20 |
| 09-19-03 | PDA ITS/CABINET - WIRING DIAGRAM | 6-5-21 |
| 09-19-03 | PDA ITS – CONNECTORS | 6-5-22 |
| 09-11-03 | 6/14 PACK OUTPUT ASSEMBLY-FRONT VIEWS | 6-5-23 |
| 07-11-03 | 6/14 PACK OUTPUT ASSEMBLY-REAR VIEWS | 6-5-24 |
| 07-11-03 | 6/14 PACK OUTPUT ASSEMBLY-WIRING DIAGRAM | 6-5-25 |
| 07-11-03 | 6 PACK O/A- CB/FLASHER DIAGRAM & ASSIGNMENT NOTE | 6-5-26 |
| 07-11-03 | 14 PACK O/A-CB/FLASHER DIAGRAM | 6-5-27 |
| 09-19-03 | 6/14 PACK OUTPUT ASSEMBLY CONNECTORS | 6-5-28 |
| 07-11-03 | AMU TO OUTPUT ASSEMBLY INTERCONNECT | 6-5-29 |
| 12-01-03 | SERIAL BUS #1 & #2 TERMINATOR UNIT | 6-5-30 |